

Restoration Specialists

Thank you for custom,

After receiving your new key please check the blade fits and its operation is correct. Then you will need to sync the key and one of our keys has two choices the normal Land Rover method listed below as METHOD 1 & our active sync method Listed as METHOD 2.

When buying keys remotely sometimes and very rarely things might go wrong. Please be assured if something is not right we will sort it.

Method 1:

Hold the lock button on the fob and keep it pressed insert the key and turn to the lock position for 3 seconds turn back to the centre remove key release the lock button operate the fob.

Method 2:

- In order to enter Active Resynchronisation Mode:
- 1. Stand close to the car.
- 2. Press and hold the Unlock button down.
- 3. Whilst still holding the Unlock button, press the Lock button 3 times.

4. Then release the Unlock button Make sure that the remote is kept near to the vehicle, as the remote is now transmitting all permutations of the rolling code for that particular vehicle. This process can take up to 5 minutes.

When the car starts to respond to the data from the remote, press either button on the remote, and hold for a second. The remote will retain the last rolling code sent, and will revert to normal operation. After about 5 minutes, the remote will have tried all permutations of rolling code, at this point the operation will time out, and the remote will revert to normal operation.



